

Hosted PBX by Golden West

Park and Hold

On your phone system, hold is a local function. This means a call held on your phone cannot be picked up at another station. Park is a system-wide function. This means a call parked at one phone may be picked up by any phone.

To park a call

1. Dial *** in an active call from any phone. Press Transfer 7000 Transfer in an active call from any phone.
2. Hang up.

To retrieve the parked call, dial *557000 where 7000 is the call park extension.

