

Hosted PBX by Golden West

Installing a Phone at Home

To install a phone at home, you need an Ethernet cable and an AC power supply.

1. Plug either end of the Ethernet cable into the phone's LAN jack.
2. Connect the other end of the cable to your home router or switch.
3. Connect the supplied the AC adapter to the phone and to a working AC outlet. The phone is now ready for use.

Note: Your provider cannot guarantee call quality or reliability with phones not on the provider's data network. In addition, E911 services might not work properly when removing a phone from the office.

